



Statement of Volatility – Dell DR4100 and DR6000

Dell DR4100 and DR6000 contain both volatile and non-volatile (NV) components. Volatile components lose their data immediately upon removal of power from the component. Non-volatile components continue to retain their data even after the power has been removed from the component. Components chosen as user-definable configuration options (those not soldered to the motherboard) are not included in the Statement of Volatility. Configuration option information (pertinent to options such as microprocessors, remote access controllers, and storage controllers) is available by component separately. The following NV components are present in the Dell DR4100 and DR6000 systems. Note that the Dell DR6000 system will always have a **WAM 2** NVRAM card; whereas, the DR 4100 may have a **WAM 1** or a **WAM 2** card installed.

Item	Non-Volatile or Volatile	Quantity	Reference Designator	Size
Planer				
PCH Internal CMOS RAM	Non-Volatile	1	U_PCH	256 Bytes
BIOS SPI Flash	Non-Volatile	1	U_SPI_BIOS	8 MB
iDRAC SPI Flash	Non-Volatile	1	U_IDRAC_SPI	4 MB
BMC EMMC	Non-Volatile	1	U_EMMC	4 GB
CPU Vcore and VSA Regulators	Non-Volatile	2	U11, U12	4.25 KB
System CPLD RAM	Volatile	1	U_CPLD	1 KB
System Memory	Volatile	Up to 12 per CPU	CPU<2:1>_CH<3:0>_D<2:0>	Up to 32GB per DIMM
Internal USB Key	Non-Volatile	Up to 1	N/A	Varies (not factory installed)
Trusted Platform Module (TPM)	Non-Volatile	1	U_TPM	128 Bytes
Power Supplies				
PSU FW	Non-Volatile	1 per PSU	Varies by part number	Up to 2MB. Varies by part number
8x2.5" Backplane				
SEP internal flash	Non-Volatile	1	U_SEP	Flash: 32KB+4KB EEPROM: 1KB

Item	Non-Volatile or Volatile	Quantity	Reference Designator	Size
2x2.5" Backplane				
SEP internal flash	Non-Volatile	1	U_SEP	Flash:32KB+4KB EEPROM: 1KB
12x3.5" Backplane				
Flash memory	Non-Volatile	1	U_FLASH	32 Mb
BP FRU image	Non-Volatile	1	U_BP_FRU	256 Bytes
Expander FRU image	Non-Volatile	1	U_EXP_FRU	512 Bytes
H710, H810, H710M PERCs				
NVSRAM	Non-volatile	1	U1033	128KB
FRU	Non-volatile	1	U1019	256B
1-Wire EEPROM	Non-volatile	1	U1004	128B
SPD	Non-volatile	1	U22	256B
SBR	Non-volatile	1	U1020	8KB
SPI Flash	Non-volatile	1	U1055	2MB
Flash	Non-volatile	1	U1031	16MB

Item	Non-Volatile or Volatile	Quantity	Reference Designator	Size
ONFI Backup Flash	Non-volatile	1	U4	4GB
SDRAM	Volatile	5	U1043-U1047	512MB/1GB
NVRAM (WAM 2) Card				
DDR3 SODIMM	Volatile	1	J1	8GB
NAND Flash	Non-Volatile	1	U10, U11, U17, U18	64Gbit
Boot Flash (NOR)	Non-Volatile	1	U12	8MB
EEPROM	Non-Volatile	1	U46	2Kbit
Monet Serial Flash	Non-Volatile	1	U21	16Mbit
Monet DDR	Volatile	1	U13	2Gb
NVSRAM Flash	Non-Volatile	1	U1	1Mbit
NVRAM (WAM 1) Card				
DDR2 RDIMM	Volatile	1	J1	8 GB
NAND Flash	Non-Volatile	4	U56, U57, U58, U59	32 GB
Boot Flash (NOR)	Non-Volatile	1	U9	8 MB
EEPROM	Non-Volatile	1	U2	2K bit
Van Gogh Serial Flash	Non-Volatile	1	U47	4Mb
Van Gogh DDR2	Volatile	1	U45	128 Mb
NVSRAM Flash	Non-Volatile	1	U7	1 Mbit

Item	Type (e.g. Flash PROM, EEPROM)	Can user programs or operating system write data to it during normal operation?
Planer		
PCH Internal CMOS RAM	Battery-backed CMOS RAM	No
BIOS SPI Flash	SPI Flash	No
iDRAC SPI Flash	SPI Flash	No
BMC EMMC	eMMC NAND Flash	No
CPU Vcore and VSA Regulators	OTP(one time programmable)	No
System CPLD RAM	RAM	No
System Memory	RAM	Yes

Item	Type (e.g. Flash PROM, EEPROM)	Can user programs or operating system write data to it during normal operation?
Internal USB Key	Flash	Yes
Trusted Platform Module (TPM)	EEPROM	Yes

Item	Type (e.g. Flash PROM, EEPROM)	Can user programs or operating system write data to it during normal operation?
Power Supplies		
PSU FW	Embedded microcontroller flash	No
2x2.5" Backplane		
SEP internal flash	Integrated Flash+EEPROM	No
8x3.5" Backplane		
SEP internal flash	Integrated Flash+EEPROM	No
12x3.5" Backplane		
Flash memory	Flash	No
BP FRU image	I2C EEPROM	No
Expander FRU image	I2C EEPROM	No
H710, H810, H710M PERCs		
NVS RAM	NVS RAM	No
FRU	FRU	No
1-Wire EEPROM	1-Wire EEPROM	No
SPD	SPD	No
SBR	SBR	No
SPI Flash	SPI Flash	No
Flash	Flash	No

Item	Type (e.g. Flash PROM, EEPROM)	Can user programs or operating system write data to it during normal operation?
ONFI Backup Flash	ONFI Backup Flash	No
SDRAM	SDRAM	No
NVRAM (WAM2) Card		
DDR3 SODIMM	DIMM	Yes
NAND Flash	Flash	No
Boot Flash (NOR)	Flash	No
EEPROM	Flash	No
Monet Serial Flash	Flash	No
Monet DDR	SDRAM	No
NVSRAM Flash	Flash	No
NVRAM (WAM1) Card		
DDR2 RDIMM	DIMM	Yes
NAND Flash	Flash	No
Boot Flash (NOR)	Flash	No
EEPROM	Flash	No
Van Gogh Serial Flash	Flash	No
Van Gogh DDR2	SDRAM	No
NVSRAM Flash	Flash	No

Item	Purpose? (e.g. boot code)	How is data input to this memory?
Planer		
PCH Internal CMOS RAM	Real-time clock and BIOS configuration settings	BIOS
BIOS SPI Flash	Boot code, system configuration information, UEFI environment, Flash descriptor, ME	SPI interface via iDRAC
iDRAC SPI Flash	iDRAC Uboot (bootloader), server management persistent store (i.e. IDRAC MAC Address, iDRAC boot variables), lifecycle log cache, virtual planar FRU and EPPID, rac log, system event log, JobStore, iDRAC Secure boot code,	SPI interface via iDRAC

Item	Purpose? (e.g. boot code)	How is data input to this memory?
BMC EMMC	Operational iDRAC FW, Lifecycle Controller (LC) USC partition, LC service diags, LC OS drivers, USC firmware	NAND Flash interface via iDRAC
CPU Vcore and VSA Regulators	Operational parameters	Once values are loaded into register space a command writes to NVMEM.
System CPLD RAM	Not utilized	Not utilized

Item	Purpose? (e.g. boot code)	How is data input to this memory?
System Memory	System OS RAM	System OS
Internal USB Key	General purpose USB key drive	USB interface via PCH. Accessed via system OS
Trusted Platform Module (TPM)	Storage of encryption keys	Using TPM Enabled operating systems
Power Supplies		
PSU FW	Power Supply operation, power management data and fault behaviors	Different vendors have different utilities and tools to load the data to memory. It can also be loaded by Dell Update Package from LC or OS (Windows and Linux)
2x2.5" Backplane		
SEP internal flash	Firmware + FRU	I2C interface via iDRAC
12x3.5" Backplane		
Flash memory	Firmware	Common Flash memory Interface (CFI)
BP FRU image	FRU	I2C interface via iDRAC
Expander FRU image	FRU	I2C interface via iDRAC
H710, H810, H710M PERCs		
NVSRAM	Configuration data	ROC writes configuration data to NVSRAM

Item	Purpose? (e.g. boot code)	How is data input to this memory?
FRU	Card manufacturing information	Programmed at ICT during production.
1-Wire EEPROM	Holds default controller properties/settings	ROC writes data to this memory
SPD	Memory configuration data	Pre-programmed before assembly
SBR	Bootloader	Pre-programmed before assembly
SPI Flash	FPGA configuration data	Pre-programmed before assembly. Can be updated using Dell/LSI tools
Flash	Card firmware	Pre-programmed before assembly. Can be updated using Dell/LSI tools
ONFI Backup Flash	Holds cache data during power loss	FPGA backs up DDR data to this device in case of a power failure
SDRAM	Cache for HDD I/O	ROC writes to this memory - using it as cache for data IO to HDDs
NVRAM (WAM 2) Card		
DDR3 SODIMM	Holds user written data	User Application writes data to this memory
NAND Flash	Data in DIMM flushed to NAND Flash on power fail	NVRAM Card Firmware writes data to this memory
Boot Flash (NOR)	Used for program store and VPD	NVRAM Card Software update utility writes data to this memory
EEPROM	Not currently used	Not currently used
Monet Serial Flash	Monet Firmware store	NVRAM Card Firmware writes data to this memory
Monet DDR	Memory for Monet	NVRAM Card Firmware writes data to this memory
NVSRAM Flash		NVRAM Card Firmware writes data to this memory
NVRAM (WAM1) Card		
DDR2 RDIMM	Holds user written data	User Application writes data to this memory
NAND Flash	Data in DIMM flushed to NAND Flash on power fail	NVRAM Card Firmware writes data to this memory
Boot Flash (NOR)	Used for program store and VPD	NVRAM Card Software update utility writes data to this memory
EEPROM	Not currently used	Not currently used
Van Gogh Serial Flash	Van Gogh Firmware store	NVRAM Card Firmware writes data to this memory
Van Gogh DDR2	Memory for Van Gogh	NVRAM Card Firmware writes data to this memory
NVSRAM Flash		NVRAM Card Firmware writes data to this memory

Item	How is this memory write protected?	How is the memory cleared?
Planer		
PCH Internal CMOS RAM	N/A – BIOS only control	1) Set NVRAM_CLR jumper to clear BIOS configuration settings at boot and reboot system; 2) AC power off system, remove coin cell battery for 30 seconds, replace battery and power back on; 3) restore default configuration in F2 system setup menu.
BIOS SPI Flash	Software write protected	Not possible with any utilities or applications and system is not functional if corrupted/removed.
iDRAC SPI Flash	Embedded iDRAC subsystem firmware actively controls sub area based write protection as needed.	Not completely user clearable; however, user data, lifecycle log and archive, SEL, fw image repository can be cleared via Delete Configuration and Retire System, accessible in Lifecycle Controller interface
BMC EMMC	Embedded FW write protected	Not completely user clearable; however, user data, lifecycle log and archive, SEL, fw image repository can be cleared via Delete Configuration and Retire System, accessible in Lifecycle Controller interface
CPU Vcore and VSA Regulators	There are passwords for different sections of the register space	Not user clearable
System CPLD RAM	Not accessible	Not accessible
System Memory	OS Control	Reboot or power down system
Internal USB Key	No write protect	Can be cleared in system OS
Trusted Platform Module (TPM)	SW write protected	F2 Setup option
Power Supplies		
PSU FW	Protected by the embedded microcontroller. Special keys are used by special vendor provided utilities to unlock the ROM with various CRC checks during load.	Not clearable
8x2.5" Backplane		
SEP internal flash	Program write protect bit	Not user clearable

Item	How is this memory write protected?	How is the memory cleared?
2x2.5" Backplane		
SEP internal flash	Program write protect bit	Not user clearable
12x3.5" Backplane		
Flash memory	Hardware strapping	Not user clearable
BP FRU image	Hardware strapping	Not user clearable
Expander FRU image	Hardware strapping	Not user clearable
H710, H810, H710M PERCs		
NVS RAM	Not WP. Not visible to Host Processor	Cannot be cleared with existing tools available to the customer
FRU	Not WP	Cannot be cleared with existing tools available to the customer
1-Wire EEPROM	Not WP. Not visible to Host Processor	Cannot be cleared with existing tools available to the customer
SPD	Not WP. Not visible to Host Processor	Cannot be cleared with existing tools available to the customer
SBR	Not WP. Not visible to Host Processor	Cannot be cleared with existing tools available to the customer
SPI Flash	Not WP. Not visible to Host Processor	Cannot be cleared with existing tools available to the customer
Flash	Not WP. Not visible to Host Processor	Cannot be cleared with existing tools available to the customer

Item	How is this memory write protected?	How is the memory cleared?
ONFI Backup Flash	Not WP. Not visible to Host Processor	Flash can be cleared by powering up the card and allowing the controller to flush the contents to VD's. If the VD's are no longer available, cache can be cleared by going into controller bios and selecting Discard Preserved Cache.
SDRAM	Not WP. Not visible to Host Processor	Cache can be cleared by powering off the card
NVRAM (WAM 2) Card		
DDR3 SODIMM	Not WP	NVRAM Init program
NAND Flash	Not WP. Not visible to Host Processor	Cannot be cleared with existing tools available to the customer
Boot Flash (NOR)	Not WP.	Cannot be cleared with existing tools available to the customer
EEPROM	Not currently used	Not currently used
Monet Serial Flash	Not WP. Not visible to Host Processor	Cannot be cleared with existing tools available to the customer
Monet DDR	Not WP. Not visible to Host Processor	Cannot be cleared with existing tools available to the customer
NVSRAM Flash	Not WP. Not visible to Host Processor	Cannot be cleared with existing tools available to the customer
NVRAM (WAM 1) Card		
DDR2 RDIMM	Not WP	NVRAM Init program
NAND Flash	Not WP. Not visible to Host Processor	Cannot be cleared with existing tools available to the customer
Boot Flash (NOR)	Not WP	Cannot be cleared with existing tools available to the customer
EEPROM	Not currently used	Not currently used
Van Gogh Serial Flash	Not WP. Not visible to Host Processor	Cannot be cleared with existing tools available to the customer
Van Gogh DDR2	Not WP. Not visible to Host Processor	Cannot be cleared with existing tools available to the customer
NVSRAM Flash	Not WP. Not visible to Host Processor	Cannot be cleared with existing tools available to the customer



NOTE: For any information that you may need, direct your questions to your Dell Marketing contact.

© 2014 Dell Inc.

Trademarks used in this text: Dell™, the DELL logo, and PowerEdge™ are trademarks of Dell Inc.